



How are E3 keys programmed?

E3 keys can be programmed in various ways.

This can be done directly in the key output.

The key mode must be set in the locking chart.

Then the inserted E3 key can be programmed directly. By double-clicking in the locking chart, a lightning symbol appears with which the programming is directly transferred to the inserted key.

It is also possible to prepare the E3 key programming in the locking chart if the key is not inserted. The programming is prepared in the locking chart and by later inserting the key in the esk programming device, the programming is carried out automatically.

[Link zum FAQ-Eintrag](#) | Status as of: 28.12.2022 | RedTeam