



What must be considered when commissioning CLM Remote?

Please note the [system requirements \(47.9 KB\)](#) in advance.

Furthermore, the order of commissioning according to the [QuickGuide \(95.1 KB\)](#) (enclosed with the controller) must be observed. It is particularly important that the controller is first connected to the network and then to the power supply.

[Link zum FAQ-Eintrag](#) | Status as of: 27.07.2023 | SBB