



How does the key validity extension work for CLM Remote?

The setting works in 15min steps and applies to all E2 and E3 keys of the locking system. Afterwards, individual keys can be removed from the validation.

You can see the application in the following video:

[Link zum FAQ-Eintrag](#) | Status as of: 27.07.2023 | SBB