



Installation Instructions
 Montage- und Installationsanleitung









D1005802









www.assaabloy.de





CE	Abloy Oy, PO Box 108 80101 Joensuu Finland			16			
					DC700	EN 1154:1996/A1:2002/AC:2006 2812-CPR-AD5238	3
Dangerous substances: None							









2a




2b




















2c



2d













Dimensions
Abmessungen




Mounting Dimensions
Anschlagmaße






DC700G-FT Type 24 V DC
DC700G-FT Ausführung 24 V DC




332 ... F91




* Connection at effeff Escape Door Control units.
Anschluss an effeff-Fluchttürsteuergeräte.

⚠ Voltage of Strike and Control unit have to be the same!
Die Spannungen von Steuergerät und Türöffner müssen identisch sein!

DC700G-FT Type 12 V DC
DC700G-FT Ausführung 12 V DC



332 ... E91



ASSA ABLOY

ASSA ABLOY
Sicherheitstechnik GmbH

Bildstockstraße 20
72458 Albstadt
GERMANY
Tel.: +49 (0) 74 31-12 3-0
Fax: +49 (0) 74 31-12 3-24 0
albstadt@assaabloy.de